



SERVICE MANUAL


HYDROSTATIC TRANSMISSION

TX25H

SERVICE MANUAL

ITL

HST SPEED TRANSMISSION



INTERNATIONAL TRACTORS LIMITED

HOSHIARPUR, PUNJAB (INDIA)

Part Code No:

Publication No:
Published On:

Transmission Assembly


CONTENTS

REF. NO.	DESCRIPTION	PAGE
A	Main Dimension	2
B	Transmission Oil Filler Plug/Dipstick	3
C	Sealant and Adhesives	3
D	HST Power Flow Chart	4-5
E	Filling and Checks	6
F	Service Schedule	6
G	Special Service Tool	7-12
H	Disassembly of Differential Housing	14-41
I	Disassembly of Trumpet Housing	42-43
J	Disassembly of Tail Pinion Shaft	44-46
K	Disassembly of Range Lay Shaft	47-49
L	Disassembly of PTO Sub Assembly	50
M	Disassembly Differential Cage Sub	51-52
N	Torque Chart-Differential Housing	53
O	Differential Sub Cage Assembly	54-56
P	Assembly of Tail Pinion Shaft	57-59
Q	Procedure of Shim Selection for Tail Pinion Shaft	60
R	Range Lay Shaft Assembly	61-63
S	4WD Shaft Sub Assembly	64
T	PTO Sub Assembly	65
U	Assembly of Trumpet Housing	66-68
V	Assembly of Drop Box Mid PTO	69-73
X	Assembly of Differential Housing	74-96
Y	Differential Backlash Adjustment	97
Z	Troubleshooting	98-99


A. Main Dimensions(mm)

1. TRANSMISSION


Top View (See Main View)



Transmission Oil Drain Plugs:-




B. Transmission Oil Filler Plug/Dipstick



B.1.a Transmission Oil :-

- Capacity : 6.08 gallon(23 Litres).
- Grade : SAE-80W.
- Replacement : Every 1000 Hours.




Dipstick marks

C. Sealant and Adhesives


Gasket Sealant and Loctite	
Adhesive make and type	Technical characteristics
Sealant 5811	Flat surface sealing
Loctite 243	Bolt and Nut
Loctite 262	Tail Pinion Nut

D. HST Power Flow Chart

1. High Power Flow:-




2. Low Power Flow:-




D. HST Power Flow Chart

1. Rear PTO Power Flow:-



2. Mid PTO Power Flow:-



E. Filling and Checks

To drain and load the oil and to check the oil level the transmission must be horizontal.

Scheduled maintenance oil drain.

To drain the oil remove the level filler and the drain plug .

E.1.a Fill Transmission Oil:

Fill the transmission with oil to the maximum level marked on the level dipstick

Apply the parking brake.

Keep the speed control in NEUTRAL range.

Start the engine at idle RPM until oil circulate in system.

Keep the Hydraulic Levers in Neutral Position. Shut off the Engine

Check that the transmission oil level is in the prescribed range on the level dipstick.

If necessary, top up with oil to keep the level in the prescribed range.

Scheduled maintenance oil check.





F. Service Schedule

Specified maintenance intervals are for standard-duty use.

Severe operating conditions may require more short intervals.

Recommended intervals									Operation
50 h	250 h	500 h	750 h	1000 h	1250 h	1500 h	1750 h	2000 h	
				●				●	Change the transmission/hydraulic oil
			●			●			Change the oil suction strainer
●	●	●	●	●	●	●	●	●	Clean the Transmission Breather Assy

G. Special Service Tool

Sr. No.	Part NO.	Description	Purpose	Picture
1.	9+9 001	Mandrel	Pressing Taper Roller Bearing of Tail Pinion.	
2.	9+9 002	Mandrel	Pressing Dowel Pin DIA 10*45.	
3.	9+9 003	Mandrel	Pressing Cotter Sleeve DIA 6	
4.	9+9 004	Guiding Sleeve	4WD Oil Seal fitment	

G. Special Service Tool

Sr. No.	Part NO.	Description	Purpose	Picture
9.	9+9 009	Mandrel	Pressing Cap in Clutch Housing	
10.	9+9 010	Mandrel	Pressing Cap in Clutch Housing	
11.	9+9 011	Mandrel	Pressing Ball Bearing 6007 in Clutch Housing	
12.	9+9 012	Mandrel	Pressing Ball Bearing 6307 in Clutch Housing	

G. Special Service Tool

Sr. No.	Part NO.	Description	Purpose	Picture
5.	9+9 005	Mandrel	Pressing Ball Bearing BB 1063 in Intermediate Shaft	
6.	9+9 006	Mandrel	Pressing Ball Bearing 6305 in Lay Shaft	
7.	9+9 007	Mandrel	Pressing Ball Bearing BB1063 in Clutch Housing	
8.	9+9 008	Mandrel	Pressing Oil Seal in Clutch Housing	


G. Special Service Tool

Sr. No.	Part NO.	Description	Purpose	Picture
13.	18ME251	Mandrel	Pressing Oil Seal 25X52X10 of 4WD Output Shaft	
14.	18ME248	Mandrel	Pressing Ball Bearing 6406 in Rear Axle Bull Pinion Shaft.	
15.	18ME249	Mandrel	Pressing Ball Bearing 6304 on Lay Shaft.	
16.	18ME244	Mandrel	Pressing Ball Bearing 6205 in Transmission Housing of Rear PTO Output Shaft	


G. Special Service Tool

Sr. No.	Part NO.	Description	Purpose	Picture
17.	18ME237	Mandrel	Pressing Ball Bearing 6205 in Transmission of PTO Intermediate Shaft	
18.	18ME252	Mandrel	Pressing Oil Seal 50X68X10 in Rear Axle Housing fitment of Rear Axle Shaft	
19.	18ME235	Mandrel	Tool for tightening Withdrawal Nut	
20.	17ME113	Mandrel	Pressing Ball Bearing 6011 in Differential Cage.	




G. Special Service Tool

Sr. No.	Part NO.	Description	Purpose	Picture
21.	17ME111	Mandrel	Pressing Ball Bearing 6211 in Differential Cage.	




Transmission Assembly






H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 1</p>	<p>Step 1:</p> <ul style="list-style-type: none">i. Remove the bolts of trumpet housing.ii. Remove the rear axle and trumpet housing from differential housing.
 <p>Fig- 2</p>	<p>Step 2:</p> <ul style="list-style-type: none">i. Remove the bolts.ii. Remove the PTO valve assembly.
 <p>Fig- 3</p>	<p>Step 3:</p> <ul style="list-style-type: none">i. Remove the bolts.ii. Remove the intermediate plate.




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 893 558 933">Fig- 4</p>	<p data-bbox="944 486 1038 517">Step 4:</p> <p data-bbox="944 544 1402 575">I. Remove three split pin by using tool.</p>
 <p data-bbox="482 1428 558 1468">Fig- 5</p>	<p data-bbox="944 1004 1038 1035">Step 5:</p> <p data-bbox="944 1061 1277 1128">I. Remove the bolt. ii. Remove the locking strip.</p>
 <p data-bbox="482 1981 558 2021">Fig- 6</p>	<p data-bbox="944 1517 1038 1548">Step 6:</p> <p data-bbox="944 1574 1510 1641">I. Remove the diff. lock fork, spring, spacer and diff. lock shaft.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 557 933">Fig- 7</p>	<p data-bbox="946 488 1038 517">Step 7:</p> <ul data-bbox="946 548 1338 577" style="list-style-type: none"><li data-bbox="946 548 1338 577">I. Remove the dipstick assembly.
 <p data-bbox="484 1437 557 1470">Fig- 8</p>	<p data-bbox="946 1010 1038 1039">Step 8:</p> <ul data-bbox="946 1070 1480 1130" style="list-style-type: none"><li data-bbox="946 1070 1480 1099">i. Remove the cap from differential housing.<li data-bbox="946 1099 1480 1130">ii. Remove the internal circlip by using tool.
 <p data-bbox="484 1986 557 2021">Fig- 9</p>	<p data-bbox="946 1521 1038 1550">Step 9:</p> <ul data-bbox="946 1581 1187 1610" style="list-style-type: none"><li data-bbox="946 1581 1187 1610">I. Remove the shim.




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 574 933">Fig- 10</p>	<p data-bbox="944 488 1052 524">Step 10:</p> <p data-bbox="944 546 1433 610">i. Remove the ball bearing 6206, PTO intermediate shaft and ball bearing 6205.</p>
 <p data-bbox="484 1437 574 1473">Fig- 11</p>	<p data-bbox="944 1008 1052 1044">Step 11:</p> <p data-bbox="944 1066 1269 1101">I. Remove the PTO switch.</p>
 <p data-bbox="484 1986 574 2021">Fig- 12</p>	<p data-bbox="944 1519 1052 1555">Step 12:</p> <p data-bbox="944 1577 1329 1612">i. Remove parking brake switch.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 929">Fig- 13</p>	<p data-bbox="944 488 1052 517">Step 13:</p> <p data-bbox="944 546 1411 575">i. Remove the bolts of differential cage.</p>
 <p data-bbox="482 1433 574 1466">Fig- 14</p>	<p data-bbox="944 1008 1052 1037">Step 14:</p> <p data-bbox="944 1066 1477 1130">i. Remove the locking plate, differential cage and shims.</p>
 <p data-bbox="482 1984 574 2017">Fig- 15</p>	<p data-bbox="944 1521 1052 1550">Step 15:</p> <p data-bbox="944 1579 1437 1608">i. Remove the differential cage assembly.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 16</p>	<p>Step 16:</p> <ul style="list-style-type: none">i. Remove the bolts.ii. Remove the intermediate plate.
 <p>Fig- 17</p>	<p>Step 17:</p> <ul style="list-style-type: none">I. Remove the bolt and locking strip.
 <p>Fig- 18</p>	<p>Step 18:</p> <ul style="list-style-type: none">i. Remove the JMI PTO clutch assembly.




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 19</p>	<p>Step 19:</p> <p>i. Remove hub PTO clutch.</p>
 <p>Fig- 20</p>	<p>Step 20 :</p> <p>I. Remove the ball bearing 6005.</p>
 <p>Fig- 21</p>	<p>Step 21:</p> <p>I. Remove the ball bearing 6007.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 22</p>	<p data-bbox="946 488 1055 522">Step 22:</p> <p data-bbox="946 548 1275 581">I. Remove the needle bush.</p>
 <p data-bbox="482 1433 574 1470">Fig- 23</p>	<p data-bbox="946 1008 1055 1041">Step 23:</p> <p data-bbox="946 1068 1199 1101">I. Remove the circlip.</p>
 <p data-bbox="482 1981 574 2019">Fig- 24</p>	<p data-bbox="946 1524 1055 1557">Step 24:</p> <p data-bbox="946 1583 1328 1616">I. Remove the driven gear Z-20.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 574 933">Fig- 25</p>	<p data-bbox="944 488 1052 517">Step 25:</p> <p data-bbox="944 548 1199 577">I. Remove the circlip.</p>
 <p data-bbox="484 1440 574 1470">Fig- 26</p>	<p data-bbox="944 1008 1052 1037">Step 26:</p> <p data-bbox="944 1068 1282 1097">I. Remove driven gear Z-19.</p>
 <p data-bbox="484 1986 574 2021">Fig- 27</p>	<p data-bbox="944 1521 1052 1550">Step 27:</p> <p data-bbox="944 1581 1498 1667">I. Remove the three bolts. ii. Remove the bearing holder bracket and ball bearing 6007.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 28</p>	<p data-bbox="944 488 1052 517">Step 28:</p> <p data-bbox="944 548 1437 606">I. Remove the withdrawal nut and locking washer.</p>
 <p data-bbox="482 1435 574 1470">Fig- 29</p>	<p data-bbox="944 1010 1052 1039">Step 29:</p> <p data-bbox="944 1070 1468 1128">I. Remove the bolts of bearing holder plate. ii. Remove the bearing holder plate.</p>
 <p data-bbox="482 1984 574 2021">Fig- 30</p>	<p data-bbox="944 1521 1052 1550">Step 30:</p> <p data-bbox="944 1581 1355 1610">I. Remove the taper roller bearing.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 34</p>	<p data-bbox="944 488 1052 522">Step 34:</p> <p data-bbox="944 546 1433 608">I. Remove the shifter rod from differential housing.</p>
 <p data-bbox="482 1433 574 1470">Fig- 35</p>	<p data-bbox="944 1010 1052 1044">Step 35:</p> <p data-bbox="944 1068 1433 1130">I. Remove the shifter lug from differential housing.</p>
 <p data-bbox="482 1979 574 2017">Fig- 36</p>	<p data-bbox="944 1521 1052 1555">Step 36:</p> <p data-bbox="944 1579 1492 1641">I. Remove the tail pinion shaft and taper roller bearing.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 569 933">Fig- 31</p>	<p data-bbox="947 488 1052 524">Step 31:</p> <p data-bbox="947 548 1489 583">I. Remove the circlip, shim and thrust washer.</p>
 <p data-bbox="482 1435 569 1470">Fig- 32</p>	<p data-bbox="947 1008 1052 1044">Step 32:</p> <p data-bbox="947 1068 1355 1103">I. Remove the dog gear high Z-24.</p>
 <p data-bbox="482 1986 569 2021">Fig- 33</p>	<p data-bbox="947 1521 1052 1557">Step 33:</p> <p data-bbox="947 1581 1378 1616">I. Remove the split pin by using tool.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 574 933">Fig- 37</p>	<p data-bbox="944 488 1055 524">Step 37:</p> <p data-bbox="944 548 1459 610">I. Remove the shifter sleeve, hub, fork, dog gear low and driver gear 4WD.</p>
 <p data-bbox="482 1437 574 1473">Fig- 38</p>	<p data-bbox="944 1008 1055 1044">Step 38:</p> <p data-bbox="944 1068 1508 1130">I. Remove the PTO drive shaft and ball bearing 6005.</p>
 <p data-bbox="482 1986 574 2021">Fig- 39</p>	<p data-bbox="944 1521 1055 1557">Step 39:</p> <p data-bbox="944 1581 1494 1643">I. Remove the shim and tie the with PTO drive shaft.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 40</p>	<p data-bbox="946 486 1055 519">Step 40:</p> <p data-bbox="946 541 1454 608">I. Remove the ball bearing 6206, range lay shaft, idler gear 4WD.</p>
 <p data-bbox="482 1433 574 1470">Fig- 41</p>	<p data-bbox="946 1006 1055 1039">Step 41:</p> <p data-bbox="946 1061 1336 1094">I. Remove the ball bearing 6304.</p>
 <p data-bbox="482 1979 574 2017">Fig- 42</p>	<p data-bbox="946 1515 1055 1548">Step 42:</p> <p data-bbox="946 1570 1501 1692">I. Remove the internal circlip from differential housing. ii. Remove the external circlip from connecting sleeve PTO.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 43</p>	<p>Step 43:</p> <p>I. Remove the connecting sleeve PTO and ball bearing.</p>
 <p>Fig- 44</p>	<p>Step 44:</p> <p>I. Remove the split pin by using tool.</p>
 <p>Fig- 45</p>	<p>Step 45:</p> <p>I. Remove the pivot lug, ball and spring.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 46</p>	<p data-bbox="944 488 1052 517">Step 46:</p> <ul data-bbox="944 548 1281 608" style="list-style-type: none"><li data-bbox="944 548 1177 577">I. Remove the bolt.<li data-bbox="944 577 1281 608">ii. Remove the locking plate.
 <p data-bbox="482 1435 574 1473">Fig- 47</p>	<p data-bbox="944 1008 1052 1037">Step 47:</p> <ul data-bbox="944 1068 1381 1097" style="list-style-type: none"><li data-bbox="944 1068 1381 1097">I. Remove the bolt and nut from fork.
 <p data-bbox="482 1979 574 2017">Fig- 48</p>	<p data-bbox="944 1521 1052 1550">Step 48:</p> <ul data-bbox="944 1581 1229 1610" style="list-style-type: none"><li data-bbox="944 1581 1229 1610">I. Remove the pivot rod.




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 49</p>	<p>Step 49:</p> <p>I. Remove the fork 4WD.</p>
 <p>Fig- 50</p>	<p>Step 50:</p> <p>I. Remove the internal circlip.</p>
 <p>Fig- 51</p>	<p>Step 51:</p> <p>I. Remove the ball bearing 6304, spacer and 4WD output shaft.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 52</p>	<p>Step 52:</p> <p>I. Remove the driven gear 4WD.</p>
 <p>Fig- 53</p>	<p>Step 53:</p> <p>I. Remove the shifter sleeve 4WD.</p>
 <p>Fig- 54</p>	<p>Step 54:</p> <p>I. Remove the oil seal.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 55</p>	<p>Step 55:</p> <p>I. Remove the internal circlip from differential housing.</p>
 <p>Fig- 56</p>	<p>Step 56:</p> <p>I. Remove the ball bearing and spacer.</p>
 <p>Fig- 57</p>	<p>Step 57:</p> <p>I. Remove the bolt. ii. Remove the locking plate.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 58</p>	<p data-bbox="944 488 1052 522">Step 58:</p> <ul data-bbox="944 548 1308 610" style="list-style-type: none"><li data-bbox="944 548 1170 577">I. Remove the bolt.<li data-bbox="944 577 1308 610">ii. Remove the spring and ball.
 <p data-bbox="482 1433 574 1470">Fig- 59</p>	<p data-bbox="944 1008 1052 1041">Step 59:</p> <ul data-bbox="944 1068 1222 1101" style="list-style-type: none"><li data-bbox="944 1068 1222 1101">i. Remove the split pin.
 <p data-bbox="482 1986 574 2021">Fig- 60</p>	<p data-bbox="944 1521 1052 1555">Step 60:</p> <ul data-bbox="944 1581 1308 1643" style="list-style-type: none"><li data-bbox="944 1581 1308 1610">I. Remove the cap and circlip.<li data-bbox="944 1610 1308 1643">ii. Remove the PTO shifter rod.




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 569 929">Fig- 61</p>	<p data-bbox="944 488 1052 517">Step 61:</p> <p data-bbox="944 546 1239 575">I. Remove the cotter pin.</p>
 <p data-bbox="482 1433 569 1466">Fig- 62</p>	<p data-bbox="944 1008 1052 1037">Step 62:</p> <p data-bbox="944 1066 1472 1094">I. Remove the link PTO shifter and pivot lug.</p>
 <p data-bbox="482 1986 569 2019">Fig- 63</p>	<p data-bbox="944 1521 1052 1550">Step 63:</p> <p data-bbox="944 1579 1239 1608">I. Remove the PTO fork.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 64</p>	<p data-bbox="944 488 1052 519">Step 64:</p> <p data-bbox="944 546 1234 577">I. Remove the PTO cap.</p>
 <p data-bbox="482 1433 574 1470">Fig- 65</p>	<p data-bbox="944 1008 1052 1039">Step 65:</p> <p data-bbox="944 1066 1433 1097">I. Remove the bolts of PTO output cover.</p>
 <p data-bbox="482 1984 574 2021">Fig- 66</p>	<p data-bbox="944 1521 1052 1552">Step 66:</p> <p data-bbox="944 1579 1338 1639">I. Remove the shim. ii. Remove the PTO output shaft.</p>


H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 929">Fig- 67</p>	<p data-bbox="944 488 1052 517">Step 67:</p> <p data-bbox="944 546 1442 606">I. Remove the ball bearing 6207 and PTO output shaft.</p>
 <p data-bbox="482 1433 574 1466">Fig- 68</p>	<p data-bbox="944 1008 1052 1037">Step 68:</p> <p data-bbox="944 1066 1503 1099">I. Remove the hub, sliding gear and fixed gear.</p>
 <p data-bbox="482 1986 574 2019">Fig- 69</p>	<p data-bbox="944 1521 1052 1550">Step 69:</p> <p data-bbox="944 1579 1407 1639">I. Remove the bolts. ii. Remove the mid PTO sub assembly.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 574 933">Fig- 70</p>	<p data-bbox="946 488 1052 517">Step 70:</p> <p data-bbox="946 548 1315 577">I. Take mid PTO sub assembly.</p>
 <p data-bbox="484 1437 574 1470">Fig- 71</p>	<p data-bbox="946 1010 1052 1039">Step 71:</p> <p data-bbox="946 1070 1269 1099">I. Remove the bolt and nut.</p>
 <p data-bbox="484 1986 574 2021">Fig- 72</p>	<p data-bbox="946 1524 1052 1552">Step 72:</p> <p data-bbox="946 1583 1350 1612">I. Remove the circlip of idler shaft.</p>




H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 929">Fig- 73</p>	<p data-bbox="946 486 1050 519">Step 73:</p> <p data-bbox="946 541 1241 575">I. Remove the idler shaft.</p>
 <p data-bbox="482 1433 574 1466">Fig- 74</p>	<p data-bbox="946 1006 1050 1039">Step 74:</p> <p data-bbox="946 1061 1241 1094">I. Remove the idler gear.</p>
 <p data-bbox="482 1984 574 2017">Fig- 75</p>	<p data-bbox="946 1515 1050 1548">Step 75:</p> <p data-bbox="946 1570 1501 1636">I. Remove the ball bearings, circlip, spacer and shim.</p>


H. Dis-assembly of Differential Housing

Figure	Instruction
 <p>Fig- 76</p>	<p>Step 76:</p> <p>I. Remove the bolts.</p>
 <p>Fig- 77</p>	<p>Step 77:</p> <p>I. Remove the seal stopper.</p>
 <p>Fig- 78</p>	<p>Step 78:</p> <p>I. Remove the oil seal.</p>


H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 574 933">Fig- 79</p>	<p data-bbox="944 488 1052 524">Step 79:</p> <p data-bbox="944 546 1291 581">I. Remove the internal circlip.</p>
 <p data-bbox="484 1437 574 1473">Fig- 80</p>	<p data-bbox="944 1019 1052 1055">Step 80:</p> <p data-bbox="944 1077 1187 1112">I. Remove the shim.</p>
 <p data-bbox="484 1986 574 2021">Fig- 81</p>	<p data-bbox="944 1519 1052 1555">Step 81:</p> <p data-bbox="944 1577 1334 1612">I. Remove the ball bearing 6005.</p>


H. Dis-assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 893 558 937">Fig- 1</p>	<p data-bbox="947 468 1055 504">Step 83:</p> <p data-bbox="947 526 1340 561">I. Remove the ball Bearing 6204.</p>

I. Disassembly of Trumpet Housing



1.Unlock the locking washer by using tool and remove the locking nut (A).




2.Remove the locking washer (B), spacer (C), bearing(D), bull gear (E) and sleeve (F).




3.Remove the rear axle and oil seal. Discard the oil Seal and replace with new one during assembly.



4.Remove the bolts of brake cover.




5.Remove the brake cover.




6.Remove the split pin.


I. Disassembly of Trumpet Housing




7.Remove the bolt of brake actuating rod.




8.Remove the brake assembly.



9.Remove the brake actuating rod.




10.Remove the circlip of bull shaft bearing.




11.Remove the bull shaft (A), spacer (B) and bearing (C) and circlip (D).

J. Disassembly of Tail Pinion Shaft




Exploded View




1	Withdrawal Nut
2	Locking Washer
3	Taper Roller Bearing
4	External Circlip
5	Shim
6	Thrust Washer
7	Dog Gear High Z-24

8	Shifter Sleeve
9	Hub
10	Dog Gear Low Z-35
11	Driver Gear 4WD
12	Spacer
13	Taper Roller Bearing
14	Tail Pinion Shaft


J. Disassembly of Tail Pinion Shaft




a.Remove the withdrawal nut.




b.Remove the locking washer.




c.Remove the taper roller bearing




d.Remove the circlip.




e.Remove the shim.



f.Remove the thrust washer.




g.Remove the dog gear high Z-24.




h.Remove the shifter sleeve.


J. Disassembly of Tail Pinion Shaft




i.Remove the hub.




j.Remove the dog gear low Z-35.



k.Remove the driver gear 4WD.




l.Remove the spacer.




m.Remove the taper roller bearing.

K. Disassembly of Range Lay Shaft




Exploded View




1	Needle Bush
2	Circlip
3	Driven Gear Z-21
4	Circlip
5	Ball Bearing 6206
6	Range Lay Shaft
7	Idler Gear 4WD

8	Needle Roller Bearing
9	Spacer
10	Ball Bearing 6304


K. Disassembly of Range Lay Shaft




a.Remove the needle bush.




b.Remove the circlip.




c.Remove the driven gear Z-21.




d.Remove the circlip.




e.Remove the ball bearing 6206.



f.Remove the ball bearing 6304.




g.Remove the spacer.




h.Remove the idler gear 4WD.

K. Disassembly of Range Lay Shaft




a. Remove the needle roller bearing.

L. Disassembly of PTO Sub Assembly





Exploded View



1	Circlip
2	Ball Bearing
3	Connecting Sleeve PTO
4	Circlip
5	Ball Bearing 6205
6	PTO Intermediate Shaft
7	Spacer

8	Ball Bearing 6206
9	Ball Bearing 6205
10	Hub PTO
11	Sliding Gear PTO Z-43
12	Fixed Gear Z-60
13	Needle Roller Bearing
14	PTO Output Shaft
15	Ball Bearing 6207

M. Dis-assembly Differential Cage Sub:-



1	Ball Bearing 6011
2	Diff Side Gear Liner
3	Diff. Side Gear 14T
4	Thrust Washer
5	Spring Cotter Sleeve
6	Diff Pinion Gear 10T

7	Bolt
8	Locking Washer
9	Diff Cage Assembly
10	Crown Wheel
11	Ball Bearing 6211

M. Disassembly of Differential Sub Cage



a. Remove the differential cage ball bearing 6011.




b. Remove the differential cage ball bearing 6211.




c. Remove the spring cotter sleeve.



d. Remove the pinion shaft.




e. Remove the differential pinion gear.



f. Remove the all differential side gear, thrust washer and liner.





g. Remove the bolt and locking washer.





h. Remove the crown wheel.

N. Torque Chart-Differential Housing




O. Differential Sub Cage Assembly




1	Ball Bearing 6011
2	Diff Side Gear Liner
3	Diff. Side Gear 14T
4	Thrust Washer
5	Spring Cotter Sleeve
6	Diff Pinion Gear 10T

7	Bolt
8	Locking Washer
9	Diff Cage Assembly
10	Crown Wheel
11	Ball Bearing 6211


O. Differential Sub Cage Assembly




a. Take the differential cage.




b. Assemble the crown wheel in RHS of differential cage. Plain face of the crown wheel towards cage side.



c. Tight the bolts of diff. cage and lock the locking strip. Torque= 13.28-16.96 lbf.ft (18-23 Nm). Loctite 243



d. Press the LHS ball bearing 6211 on the differential cage by using mandrel.




e. Assembly differential side gear.



f. Assemble the inner and outer gear with liner.


O. Differential Sub Cage Assembly




g. Assemble the second differential pinion gear with thrust washer.



h. Insert the pinion shaft.




i. Align the hole (A) of shaft with hole (B) end. Press the sleeve by using hammer.




j. Assemble ball bearing 6011 on the RHS differential cage by using mandrel.

P. Assembly of Tail Pinion Shaft




Exploded View




1	Withdrawal Nut
2	Locking Washer
3	Taper Roller Bearing
4	External Circlip
5	Shim
6	Thrust Washer
7	Dog Gear High Z-24

8	Shifter Sleeve
9	Hub
10	Dog Gear Low Z-35
11	Driver Gear 4WD
12	Spacer
13	Taper Roller Bearing
14	Tail Pinion Shaft


P. Assembly of Tail Pinion Shaft



1. Take tail pinion shaft and taper roller bearing.



2. Install the taper roller bearing by using mandrel 9+9 001.



3. Insert the spacer.



4. Insert the driver gear 4WD..



5. Insert the dog gear low.



6. Insert the hub.

P. Assembly of Tail Pinion Shaft



7. Insert the shifter sleeve.



8. Insert the dog gear high.



9. Insert the thrust washer.



10. Insert the circlip.


Q. Procedure of Shim Selection for Tail Pinion Shaft



Step 1: Assemble the circlip and lock the tail pinion shaft.



Step 3: Remove the circlip. Insert the shims as per required. Reassemble the circlip at its position.



Step 2: Measure the clearance between spacer and dog gear low.

Shim selection process :-

Ex.

Clearance between spacer and dog gear low = 0.25 mm (A)


Specified limit = 0.10-0.15 mm (B)

Required shim thickness = A - B


$$= 0.25 - 0.10$$

$$= 0.15 \text{ mm}$$

R. Range Lay Shaft Assembly



Exploded View



1	Needle Bush
2	Circlip
3	Driven Gear Z-21
4	Circlip
5	Ball Bearing 6206
6	Range Lay Shaft
7	Idler Gear 4WD

8	Needle Roller Bearing
9	Spacer
10	Ball Bearing 6304

R. Assembly of Range Lay Shaft



a. Insert the needle roller bearing.



b. Insert the idle gear 4WD.



c. Insert the spacer.



d. Insert the ball bearing 6304.



e. Insert the spacer.



f. Insert the circlip.

R. Assembly of Range Lay Shaft



g. Insert the driven gear.




h. Insert the circlip.




i. Insert the needle bush.

S. 4WD Shaft Sub Assembly :-




Exploded View




1	Ball Bearing 6205
2	Spacer
3	Driven Gear 4WD
4	Shifter Sleeve
5	4WD Output Shaft
6	Spacer
7	Ball Bearing 6304

T. PTO Sub Assembly




Exploded View




1	Circlip
2	Ball Bearing
3	Connecting Sleeve PTO
4	Circlip
5	Ball Bearing 6205
6	PTO Intermediate Shaft
7	Spacer

8	Ball Bearing 6206
9	Ball Bearing 6205
10	Hub PTO
11	Sliding Gear PTO Z-43
12	Fixed Gear Z-60
13	Needle Roller Bearing
14	PTO Output Shaft
15	Ball Bearing 6207


U. Assembly of Trumpet Housing




1. Assemble ball bearing 6406 in trumpet housing by using mandrel 18ME248 and insert spacer, bull pinion shaft.




2. Lock the external circlip.




3. Lock the internal circlip.



4. Assemble the brake actuating shaft.




5. Insert the brake assembly.




6. Insert the bolt in brake assemble and engage with brake actuating shaft.


U. Assembly of Trumpet Housing




7. Insert the cotter pin.




8. Apply sealant 5811 on the brake cover.




9. Apply loctite on the bolts and tight the bolts of brake cover.(loctite 243)
Torque= 13.28-18.44 lbf.ft (18-25 Nm).



10. Assemble the brake cover.




11. Assemble the oil seal in brake housing by using mandrel 18ME252 .




12. Assemble the ball bearing 6209 in brake housing.


U. Assembly of Trumpet Housing



13. Assemble the rear axle.






14. Insert the spacer, bull gear and assemble ball bearing 6308 by using mandrel HST 07 . Insert spacer, lock washer.






15. Tight the locking nut by using tool 18ME235.
Torque= 44.25-51.63 lbf.ft (60-70 NM)




V. Assembly of Drop Box Mid PTO:

Figure	Instruction
 <p data-bbox="482 898 557 933">Fig- 1</p>	<p data-bbox="944 488 1038 524">Step 1:</p> <p data-bbox="944 548 1338 583">I. Remove the ball Bearing 6204.</p>
 <p data-bbox="482 1437 557 1473">Fig- 2</p>	<p data-bbox="944 1010 1038 1046">Step 2:</p> <p data-bbox="944 1070 1494 1134">I. Assemble the mid PTO output shaft and ball bearing 6005.</p>
 <p data-bbox="482 1993 557 2028">Fig- 3</p>	<p data-bbox="944 1521 1038 1557">Step 3:</p> <p data-bbox="944 1581 1152 1616">I. Insert the shim.</p>




V. Assembly of Drop Box Mid PTO:

Figure	Instruction
 <p data-bbox="484 898 557 933">Fig- 4</p>	<p data-bbox="946 488 1038 517">Step 4:</p> <p data-bbox="946 546 1308 575">I. Assemble the internal circlip.</p>
 <p data-bbox="484 1437 557 1470">Fig- 5</p>	<p data-bbox="946 1010 1038 1039">Step 5:</p> <p data-bbox="946 1068 1229 1097">I. Assemble the oil seal.</p>
 <p data-bbox="484 1986 557 2021">Fig- 6</p>	<p data-bbox="946 1528 1038 1557">Step 6:</p> <p data-bbox="946 1586 1324 1614">I. Assemble the oil seal stopper.</p>


V. Assembly of Drop Box Mid PTO:

Figure	Instruction
 <p data-bbox="482 895 558 933">Fig- 7</p>	<p data-bbox="946 491 1038 522">Step 7:</p> <p data-bbox="946 550 1201 581">I. Assemble the bolts.</p> <p data-bbox="946 608 1350 639">Torque : 3.69-7.38 lbf.ft(5-10 Nm).</p>
 <p data-bbox="482 1433 558 1470">Fig- 8</p>	<p data-bbox="946 1019 1038 1050">Step 8:</p> <p data-bbox="946 1079 1492 1141">I. Assemble ball bearings, idler gear mid PTO, circlip, spacer and shim.</p>
 <p data-bbox="482 1986 558 2021">Fig- 9</p>	<p data-bbox="946 1521 1038 1552">Step 9:</p> <p data-bbox="946 1581 1489 1612">I. Assemble the idler gear mid PTO assembly.</p>




V. Assembly of Drop Box Mid PTO:

Figure	Instruction
 <p data-bbox="482 895 574 929">Fig- 10</p>	<p data-bbox="946 491 1055 524">Step 10:</p> <p data-bbox="946 548 1385 581">I. Assemble the idler shaft mid PTO..</p>
 <p data-bbox="482 1433 574 1466">Fig- 11</p>	<p data-bbox="946 1004 1055 1037">Step 11:</p> <p data-bbox="946 1061 1315 1094">I. Assemble the external circlip.</p>
 <p data-bbox="482 1986 574 2019">Fig- 12</p>	<p data-bbox="946 1526 1055 1559">Step 12:</p> <p data-bbox="946 1583 1241 1616">I. Assemble bolt and nut.</p>




V. Assembly of Drop Box Mid PTO:

Figure	Instruction
 <p data-bbox="482 895 574 929">Fig- 13</p>	<p data-bbox="947 488 1055 522">Step 13:</p> <p data-bbox="947 548 1451 610">I. Assemble the bolts of drop box mid PTO assembly.</p> <p data-bbox="947 637 1399 670">Torque : 22.13-29.50 lbf.ft (30-40 Nm)</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 557 933">Fig- 1</p>	<p data-bbox="947 482 1038 517">Step 1:</p> <p data-bbox="947 539 1482 606">I. Assemble ball bearings 6205 in differential housing.</p>
 <p data-bbox="482 1437 557 1473">Fig- 2</p>	<p data-bbox="947 1008 1038 1044">Step 2:</p> <p data-bbox="947 1066 1454 1132">I. Insert the spacer, PTO sliding gear, hub, needle roller bearings and PTO fixed gear.</p>
 <p data-bbox="482 1977 557 2012">Fig- 3</p>	<p data-bbox="947 1526 1038 1561">Step 3:</p> <p data-bbox="947 1583 1496 1650">I. Insert the ball bearing 6207 and PTO output shaft.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 558 933">Fig- 4</p>	<p data-bbox="944 488 1038 524">Step 4:</p> <p data-bbox="944 548 1156 583">I. Insert the shim.</p>
 <p data-bbox="482 1437 558 1473">Fig- 5</p>	<p data-bbox="944 1008 1038 1044">Step 5:</p> <p data-bbox="944 1068 1503 1130">I. Assemble the oil seal and PTO output cover. Tight the bolts.</p> <p data-bbox="944 1159 1385 1221">Torque: 13.28-16.96 lbf.ft(18-23 Nm) Loctite 5188</p>
 <p data-bbox="482 1986 558 2021">Fig- 6</p>	<p data-bbox="944 1521 1038 1557">Step 6:</p> <p data-bbox="944 1581 1253 1616">I. Assemble the PTO cap.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 557 931">Fig- 7</p>	<p data-bbox="946 482 1038 515">Step 7:</p> <p data-bbox="946 539 1204 572">I. Insert the PTO fork.</p>
 <p data-bbox="484 1437 557 1470">Fig- 8</p>	<p data-bbox="946 1008 1038 1041">Step 8:</p> <p data-bbox="946 1066 1489 1099">I. Assemble the link PTO shifter and pivot lug.</p>
 <p data-bbox="484 1986 557 2019">Fig- 9</p>	<p data-bbox="946 1526 1038 1559">Step 9:</p> <p data-bbox="946 1583 1256 1616">I. Assemble the cotter pin.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 574 933">Fig- 10</p>	<p data-bbox="944 482 1055 517">Step 10:</p> <ul data-bbox="944 539 1367 606" style="list-style-type: none"><li data-bbox="944 539 1281 570">I. Insert the PTO shifter rod.<li data-bbox="944 570 1367 606">ii. Assemble the cap and circlip (A).
 <p data-bbox="482 1437 574 1473">Fig- 11</p>	<p data-bbox="944 1008 1055 1044">Step 11:</p> <ul data-bbox="944 1066 1281 1101" style="list-style-type: none"><li data-bbox="944 1066 1281 1101">i. Assemble the split pin (B).
 <p data-bbox="482 1981 574 2017">Fig- 12</p>	<p data-bbox="944 1526 1055 1561">Step 12:</p> <ul data-bbox="944 1583 1281 1650" style="list-style-type: none"><li data-bbox="944 1583 1281 1614">I. Insert the ball and spring.<li data-bbox="944 1614 1142 1650">ii. Tight the bolt.




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 574 933">Fig- 13</p>	<p data-bbox="947 484 1055 515">Step 13:</p> <ul data-bbox="947 544 1295 603" style="list-style-type: none"><li data-bbox="947 544 1295 575">I. Assemble the locking plate.<li data-bbox="947 577 1295 603">ii. Tight the bolt. <p data-bbox="947 632 1381 692">Torque: 13.28-16.96 lbf.ft(18-23 Nm) Loctite 5188</p>
 <p data-bbox="482 1433 574 1468">Fig- 14</p>	<p data-bbox="947 1010 1055 1041">Step 14:</p> <ul data-bbox="947 1070 1425 1101" style="list-style-type: none"><li data-bbox="947 1070 1425 1101">I. Assemble the ball bearing and spacer.
 <p data-bbox="482 1981 574 2017">Fig- 15</p>	<p data-bbox="947 1528 1055 1559">Step 15:</p> <ul data-bbox="947 1588 1494 1647" style="list-style-type: none"><li data-bbox="947 1588 1494 1647">I. Assemble the internal circlip from differential housing.




X. Assembly of Differential Housing

Figure	Instruction
 <p>Fig- 16</p>	<p>Step 16:</p> <p>I. Insert the shifter sleeve 4WD.</p>
 <p>Fig- 17</p>	<p>Step 17:</p> <p>I. Insert the driven gear 4WD.</p>
 <p>Fig- 18</p>	<p>Step 18:</p> <p>I. Assemble the ball bearing 6304, spacer and 4WD output shaft.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p>Fig- 19</p>	<p>Step 19:</p> <p>I. Assemble the internal circlip.</p>
 <p>Fig- 20</p>	<p>Step 20:</p> <p>I. Assemble the fork 4WD.</p>
 <p>Fig- 21</p>	<p>Step 21:</p> <p>I. Assemble the oil seal.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 22</p>	<p data-bbox="944 482 1055 515">Step 22:</p> <p data-bbox="944 539 1486 603">I. Insert the ball and spring and assemble the pivot lug.</p>
 <p data-bbox="482 1433 574 1470">Fig- 23</p>	<p data-bbox="944 1008 1055 1041">Step 23:</p> <p data-bbox="944 1066 1447 1099">I. Assemble the split pin (A) by using tool.</p>
 <p data-bbox="482 1984 574 2021">Fig- 24</p>	<p data-bbox="944 1524 1055 1557">Step 24:</p> <p data-bbox="944 1581 1468 1645">I. Assemble the connecting sleeve PTO and ball bearing.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 574 933">Fig- 25</p>	<p data-bbox="944 482 1055 517">Step 25:</p> <p data-bbox="944 539 1251 575">I. Assemble the pivot rod.</p>
 <p data-bbox="482 1437 574 1473">Fig- 26</p>	<p data-bbox="944 1008 1055 1044">Step 26:</p> <p data-bbox="944 1066 1229 1101">I. Tight the bolt and nut.</p> <p data-bbox="944 1128 1385 1163">Torque: 13.28-16.96 lbf.ft(18-23 Nm)</p>
 <p data-bbox="482 1986 574 2021">Fig- 27</p>	<p data-bbox="944 1526 1055 1561">Step 27:</p> <p data-bbox="944 1583 1303 1650">I. Assemble the locking plate. ii. Tight the bolt.</p> <p data-bbox="944 1676 1385 1743">Torque: 13.28-16.96 lbf.ft(18-23 Nm) Loctite 5188</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p>Fig- 28</p>	<p>Step 28:</p> <ol style="list-style-type: none"> I. Assemble the external circlips (A) from connecting sleeve PTO. ii. Assemble the internal circlip (B) from differential housing.
 <p>Fig- 29</p>	<p>Step 29:</p> <ol style="list-style-type: none"> I. Remove the ball bearing 6304.
 <p>Fig- 30</p>	<p>Step 30:</p> <ol style="list-style-type: none"> I. Assemble the ball bearing 6206, range lay shaft, idler gear 4WD.




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 569 933">Fig- 31</p>	<p data-bbox="947 484 1052 515">Step 31:</p> <p data-bbox="947 541 1425 603">I. Assemble the PTO drive shaft and ball bearing 6005.</p>
 <p data-bbox="484 1417 569 1453">Fig- 32</p>	<p data-bbox="947 1002 1052 1033">Step 32:</p> <p data-bbox="947 1059 1506 1121">I. Assemble the tail pinion shaft and taper roller bearing.</p>
 <p data-bbox="484 1955 569 1990">Fig- 33</p>	<p data-bbox="947 1528 1052 1559">Step 33:</p> <p data-bbox="947 1586 1482 1678">i. Insert spring, pin and ball in fork. ii. Assemble the shifter sleeve, hub, fork, dog gear low and driver gear 4WD.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 574 933">Fig- 34</p>	<p data-bbox="944 473 1052 504">Step 34:</p> <p data-bbox="944 533 1447 592">I. Assemble the shifter lug from differential housing.</p>
 <p data-bbox="484 1435 574 1470">Fig- 35</p>	<p data-bbox="944 1004 1052 1035">Step 35:</p> <p data-bbox="944 1063 1447 1123">I. Assemble the shifter rod from differential housing.</p>
 <p data-bbox="484 1984 574 2019">Fig- 36</p>	<p data-bbox="944 1519 1052 1550">Step 36:</p> <p data-bbox="944 1579 1447 1614">I. Assemble the split pin (A) by using tool.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 898 574 933">Fig- 37</p>	<p data-bbox="944 493 1055 526">Step 37:</p> <p data-bbox="944 550 1326 583">I. Insert the dog gear high Z-24.</p>
 <p data-bbox="482 1435 574 1470">Fig- 38</p>	<p data-bbox="944 1006 1055 1039">Step 38:</p> <p data-bbox="944 1063 1407 1130">I. Insert the shim and thrust washer an assemble the circlip.</p>
 <p data-bbox="482 1986 574 2021">Fig- 39</p>	<p data-bbox="944 1528 1055 1561">Step 39:</p> <p data-bbox="944 1586 1428 1619">I. Insert the shim in bearing holder plate.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 935">Fig- 40</p>	<p data-bbox="944 482 1053 515">Step 40:</p> <p data-bbox="944 541 1489 599">I. Assemble the bearing holder plate and tight the bolts.</p> <p data-bbox="944 630 1376 663">Torque:22.13-29.50 lbf.ft(30-40 Nm)</p>
 <p data-bbox="482 1437 574 1473">Fig- 41</p>	<p data-bbox="944 1010 1053 1044">Step 41:</p> <p data-bbox="944 1070 1425 1128">I. Insert the locking washer and tight the withdrawal nut.</p>
 <p data-bbox="482 1986 574 2021">Fig- 42</p>	<p data-bbox="944 1521 1053 1555">Step 42:</p> <p data-bbox="944 1581 1506 1670">I. Assemble the bearing holder bracket and ball bearing 6007. ii. Tight the three bolts.</p> <p data-bbox="944 1701 1376 1734">Torque:22.13-29.50 lbf.ft(30-40 Nm)</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="487 902 574 933">Fig- 43</p>	<p data-bbox="947 473 1052 504">Step 43:</p> <p data-bbox="947 533 1298 564">I. Assemble driven gear Z-19.</p>
 <p data-bbox="487 1440 574 1470">Fig- 44</p>	<p data-bbox="947 1008 1052 1039">Step 44:</p> <p data-bbox="947 1068 1211 1099">I. Assemble the circlip.</p>
 <p data-bbox="487 1986 574 2017">Fig- 45</p>	<p data-bbox="947 1524 1052 1555">Step 45:</p> <p data-bbox="947 1583 1343 1614">I. Assemble the driven gear Z-20.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="486 895 572 929">Fig- 46</p>	<p data-bbox="946 468 1050 502">Step 46:</p> <p data-bbox="946 530 1215 564">I. Assemble the circlip.</p>
 <p data-bbox="486 1433 572 1466">Fig- 47</p>	<p data-bbox="946 1006 1050 1039">Step 47:</p> <p data-bbox="946 1068 1293 1101">I. Assemble the needle bush.</p>
 <p data-bbox="486 1979 572 2012">Fig- 48</p>	<p data-bbox="946 1521 1050 1555">Step 48:</p> <p data-bbox="946 1583 1354 1616">I. Assemble the ball bearing 6007.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p>Fig- 49</p>	<p>Step 49:</p> <p>I. Assemble the ball bearing 6005.</p>
 <p>Fig- 50</p>	<p>Step 50:</p> <p>I. Assemble the grub screw (A) and hub PTO clutch (B).</p>
 <p>Fig- 51</p>	<p>Step 51:</p> <p>I. Assemble the JMI PTO clutch assembly.</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 574 933">Fig- 52</p>	<p data-bbox="946 488 1052 517">Step 52:</p> <p data-bbox="946 546 1447 606">I. Assemble the shifter lug from differential housing.</p>
 <p data-bbox="484 1437 574 1470">Fig- 53</p>	<p data-bbox="946 1010 1052 1039">Step 53:</p> <p data-bbox="946 1068 1494 1101">I. Assemble the locking strip and tight the bolt.</p> <p data-bbox="946 1130 1385 1163">Torque: 13.28-16.96 lbf.ft(18-23 Nm)</p>
 <p data-bbox="484 1986 574 2021">Fig- 54</p>	<p data-bbox="946 1528 1052 1557">Step 54:</p> <p data-bbox="946 1586 1367 1645">I. Assemble the intermediate plate. ii. Tight the bolts.</p> <p data-bbox="946 1674 1546 1734">M10 Bolt Torque (A): 25.81-29.50 lbf.ft(35-40 Nm.) M12 Bolt Torque(B): 44.25-51.63 lbf.ft(60-70 Nm.)</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p>Fig- 55</p>	<p>Step 55:</p> <p>I. Insert the differential cage assembly.</p>
 <p>Fig- 56</p>	<p>Step 56:</p> <p>I. Assemble the locking plate, differential cage and shims as per requirement.</p>
 <p>Fig- 57</p>	<p>Step 57:</p> <p>I. Tight the bolts (A) of differential cage.</p> <p>Torque: 13.28-16.96 lbf.ft(18-23 Nm)</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="482 895 574 933">Fig- 58</p>	<p data-bbox="946 482 1055 513">Step 58:</p> <p data-bbox="946 541 1345 572">I. Assemble parking brake switch.</p>
 <p data-bbox="482 1433 574 1470">Fig- 59</p>	<p data-bbox="946 1008 1055 1039">Step 59:</p> <p data-bbox="946 1068 1281 1099">I. Assemble the PTO switch.</p>
 <p data-bbox="482 1979 574 2017">Fig- 60</p>	<p data-bbox="946 1526 1055 1557">Step 60:</p> <p data-bbox="946 1586 1479 1647">I. Assemble the ball bearing 6205 (A), PTO intermediate shaft and ball bearing 6206 (B).</p>




X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="484 898 557 931">Fig- 7</p>	<p data-bbox="947 482 1052 515">Step 61:</p> <p data-bbox="947 539 1185 572">I. Remove the shim.</p>
 <p data-bbox="484 1440 557 1473">Fig- 62</p>	<p data-bbox="947 1010 1052 1044">Step 62:</p> <p data-bbox="947 1068 1494 1130">I. Assemble the internal circlip by using tool. ii. Assemble the cap from differential housing.</p>
 <p data-bbox="484 1993 557 2026">Fig- 63</p>	<p data-bbox="947 1526 1052 1559">Step 63:</p> <p data-bbox="947 1583 1355 1616">I. Assemble the dipstick assembly.</p>

X. Assembly of Differential Housing

Figure	Instruction
 <p>Fig- 64</p>	<p>Step 64:</p> <p>I. Assemble the diff. lock fork, spring, spacer and diff. lock shaft.</p>
 <p>Fig- 65</p>	<p>Step 65:</p> <p>I. Assemble the locking strip. ii. Tight the bolt.</p> <p>Torque: 13.28-16.96 lbf.ft(18-23 Nm)</p>
 <p>Fig- 66</p>	<p>Step 66:</p> <p>I. Assemble three split pin by using tool.</p>

X. Assembly of Differential Housing

Figure	Instruction
 <p data-bbox="486 895 572 929">Fig- 67</p>	<p data-bbox="946 475 1050 508">Step 67:</p> <ul data-bbox="946 541 1362 608" style="list-style-type: none"><li data-bbox="946 541 1362 575">I. Assemble the intermediate plate.<li data-bbox="946 575 1362 608">ii. Tight the bolts. <p data-bbox="946 630 1380 663">Torque: 44.25-51.63 lbf.ft(60-70 Nm)</p>
 <p data-bbox="486 1426 572 1459">Fig- 68</p>	<p data-bbox="946 1006 1050 1039">Step 68:</p> <ul data-bbox="946 1072 1397 1139" style="list-style-type: none"><li data-bbox="946 1072 1397 1106">I. Assemble the PTO valve assembly.<li data-bbox="946 1106 1397 1139">ii. Tight the bolts. <p data-bbox="946 1161 1380 1194">Torque: 13.28-16.96 lbf.ft(18-23 Nm)</p>
 <p data-bbox="486 1979 572 2012">Fig- 69</p>	<p data-bbox="946 1526 1050 1559">Step 69:</p> <ul data-bbox="946 1581 1501 1647" style="list-style-type: none"><li data-bbox="946 1581 1501 1614">I. Assemble the rear axle and trumpet housing.<li data-bbox="946 1614 1501 1647">ii. Tight the bolts of trumpet housing. <p data-bbox="946 1670 1380 1703">Torque: 29.50-33.19 lbf.ft(40-45 Nm)</p>

Y. Differential Backlash Adjustment

1. While slowly rotating differential carrier, lightly tap carrier with a soft-faced mallet to make sure bearing on other side of ring gear is seated.
2. Attach a dial indicator to housing, as shown, with contact point positioned on ring gear splines.

NOTE: Ring gear carrier is not preloaded and will have normal side-to-side movement.

3. While holding input shaft, move carrier and ring gear to determine differential backlash. Backlash should be within specification.

Specification

Differential Backlash—Distance0.18—0.33 mm

4. To adjust backlash, remove six cap screws (C) Turn differential quill (A) to specified angle and install cap screws in the two threaded holes. Use cap screws to draw out the quill.

Specification

Differential Quill—Angle30°




5. Remove shims (B) to decrease backlash and add shims to increase.
6. Recheck backlash after removing or adding shims.
7. Tighten differential cap screws to specification.

Specification

Differential Cap Screw—Torque.....52 N•m (43 lb-ft)

- A—Differential Quill
- B—Shim
- C—Cap Screw (6 used)

IMPORTANT: Always check and adjust backlash after cone point adjustment has been made.



Z. Troubleshooting

Gear Box :

S.NO.	PROBLEM	PROBABLE CAUSES	REMEDIES
1	NOISE		
	Humming (a peculiar noise)	Wear on gear teeth flank	Replace the gear.
		Damage on gear teeth flank	Replace the gear.
	Metallic grinding	oil level low.	Top up oil level.
	Whine (Bullet passing sound)	Backlash less	Correct the back lash either by replacing gear on housing.
		Gear machining improper	Replace the gear.
	Hissing (Leaking noise tent-tire to air lack)	worn out bearing	Replace the bearing.
		Bearing ball/race pitted	Replace the bearing.
	Rattling (Ruppict series of short loud noise)	Backlash more	Correct the back lash either by replacing gears or housing.
		Bearing seat loosen	Replace the gearing or replace the housing.
		Bearing play more	Replace the gearing.
		Excessive end play	Correct the end play by tightening the hex retaining nut or replacing spacers/gears.
	Knocking (Noise of sharp blue)	Dent on the gear tooth	Remove the dent by polishing.
		Gear tooth damage	Replace the gear.
Foreign matter present		Clean the gear train and strain the oil.	
2	HARD SHIFTING	Insufficient oil.	Top up the oil.
		Detent lock assy. Tight	Replace detent-retaining spring.
		Bent in shifter rod	Replace the shifter rod.
		Gear tooth battered	Replace the gear.
		Sliding Gears tight on shaft	Free the gear shaft by polishing or by replacing gear/shaft.
		Pilot bearing jam	Replacing the bearing
		Excessive clutch free paly	Adjust & correct free play.
		Inter-lock pin tight	Loosen the pin by polishing.
		Clutch is not disengaging.	Adjust & correct
3	GEAR SLIPPING OUT	Incomplete gear engaging	Engage gear fully.
		weak detent retaining spring	Replace the spring.
		Shifter rod retaining groove worn out	Replace the spring rod.
		Gear teeth rounded off	Replace the gear.
		Worn out / bent shifter fork	Replace the shifter fork.
4	GEAR STICKING	Detent balls/spring stuck	Free & lubrication.
		Scoring on fork.	Replace fork.
		Clutch not disengaging.	Adjust & correct.

Z. Troubleshooting

Differential :

S.NO.	TROUBLE	PROBABLE CAUSE	REMEDIES
1	Humming	1.Incorrect adjustment of crown wheel & Tail pinion. 2.Tooth contact pattern not correct.	1.Re-adjust as per procedure. 2.Correct the tooth contact pattern by doing the adjustment as per the procedure.
2	Noise while Accelerating	Tooth contact shifted toward thick end.	Adjust tooth contact pattern as per the procedure.
3	Noise while De-accelerating	Tooth contact shifted toward thick end.	Adjust tooth contact pattern as per the procedure
4	Noise while Turning	1.Bevel pinion tight on bevel gear.	1.Correct the gap.
		2.Damaged teeth of bevel	2.Replace the damaged gear.
		3.Excessive backlash between bevel pinion and bevel gear	3.Correct the backlash.
		4.Defective axle bearing	4.Replace the bearing.

Brake :

S. No.	PROBLEM	PROBABLE CAUSES	REMEDIES
1.	NO BRAKING ACTION	Pedal linkage broken or disconnected	Replace or repair
2.	POOR BRAKING ACTION	Brake setting improper	Adjust & correct
		Glazed brake liners	Replace
3.	BRAKE STUCKING	Glazed brake disc	Correct by machining or replace
		Linkage retracting spring loose	Replace springs
		Brake disc plate spring tension less	Replace springs
4.	NOISE WHILE BRAKING	Binding in linkage	Lubricant & free
		Loose rivets of brake lining	Correct or replace
		Worn out brake lining	Replace
		Rough or worn out brake disc plate	Correct by machining or replace
		Foreign matter imbedded in lining	Clean the liners
		Loose part in the system.	Tighten the loose part



SUMMIT™
—TRACTORS—