

A green Summit LX85 compact loader is parked in a grassy field. The loader has a front bucket and a rear-mounted backhoe. The background consists of a dense line of trees. The entire image is overlaid with a semi-transparent green filter. The title "Adjusting Seat Height" is centered in white text. On the left and right sides of the image, there are vertical lines of white dots.

Adjusting Seat Height

Step One

- Loosen the bolt from the rear side of the operator's seat



Steps Two & Three

- Remove the caps from both side knobs
- Loosen nut inside each knob





Step Four:

- Loosen the knobs and set the operator's seat height as needed
- Further re-tighten the knobs by rotating clock-wise and counter clock-wise

Step Five:

- Again, re-tighten the bolt from the rear side

